



LONGLIFE Series are professional listening devices that are developed for long-term standby usage. They are equipped with HQ microphones and built-in batteries.

There are different variations of the series which is equipped with same module, therefore please have a look at your packaging, in order to see how long will yours last. The starting version is LongLife 10 which lasts for 10 days.

QUICK SET-UP GUIDE:

IMPORTANT

- IT WAS NOT DEVELOPED FOR 220v CONTINUOUS USAGE
- CALLBACK FUNCTION ACTIVATION SMS= 1111 and DEACTIVATION SMS =0000
- THERE IS NO DIODE FOR CHARGING SIGNALIZATION

DIODE FLASHING SIGNALS:

- PUT SIMCARD IN: 3x flashes
- LOW BATTERY: Constant blinking

STEP 1

SETTING UP

PLUG the device into electricity and wait for it to charge. Device takes several hours to charge, depending on your battery capacity.

STEP 2

USING THE PRODUCT

Unplug the device from the electricity and give the device 10seconds to boot up. You are now able to call the de-vice, device itself will pick up the sound and you will hear from 5 to 10 meters range.

STEP 3

CALL BACK ACTIVATION

The callback function can be activated by SMS = 1111 and deactivated by sending SMS = 0000

In order to change the number, you need to take out the SIM insert a new SIM and call the number right away.



SMS COMMANDS

Call back : 1111

Deactivate callback: 0000

TECHNICAL SPECIFICATION

	STANDBY DAYS		CALLBACK DAYS		INCALL HOURS		CHARGING TIME
	MAX	MIN	MAX	MIN	MAX	MIN	HOURS
LONGLIFE 10	15.6	10.4	1.6	1.0	5.8	5.0	2.0 hrs
LONGLIFE 20	25.0	16.7	2.5	1.7	9.2	8.0	4.0 hrs
LONGLIFE 30	37.5	25.0	3.8	2.5	13.8	12.0	6.0 hrs
LONGLIFE 40	50.0	33.3	5.0	3.3	18.5	16.0	7.0 hrs
LONGLIFE 60	75.0	50.0	7.5	5.0	24-17	24.0	8.0 hrs

Operational frequency: 850MHz, 900MHz, 1800MHz, 1900MHz

DISCLAIMER

This user manual can be slightly different from specific product. Before start using the device, check your local legal terms. Neither supplier nor distributor don't assume and responsibility for using device in conflict with local law.

PACKAGE CONTENT

1. The LongLife module
2. Battery charger
3. Cable
4. 3M Sticker for easier placement

USEFUL INFORMATION

If battery is fully discharged, charging will start 3 min after connecting the device into power supply. We recommend to format battery before you start using the device. Charge the device at least 10 hours and then let it discharged. Repeat three times. After device will be fully formatted, charge it for 8 hours, ideally. Please note, quality of mobile signal in the place of installation strongly affects quality of interception. When device is not rechargeable, re-insert SIM card or re-charge the device. **When call back function doesn't work properly, even if activated, re-insert SIM card**