



**UltraLife series** is especially practical for long term surveillance devices. This module is equipped with low PIR sensor that allows you to monitor places with low activity movements for a long period of time. The module is placed manually to the covert PIR module, which makes it virtually unrecognizable from the real PIR sensor.

## QUICK SET-UP GUIDE:

- You have to set the time manually on your SD card with Notepad  
If you don't have a **external AV display**
- It comes **standardly in PIR mode** detection preset and HD resolution
- To access **OSD menu** you have to connect **AV cable** (resolution, time, length of recordings )
- You also **need external display** to access the **OSD menu**
- By pressing PIR button you will enter STANDBY mode (you can make pictures etc. with remote)
- **Battery charging can take up to 12 hours**

### STEP 1

#### SETTING UP

1. Place in SD Card ► Turn On ► MODULE IS IN PIR MODE
2. You can deactivate the PIR Mode by pressing PIR button ► YOU WILL ENTER **STANDBY**

### STEP 2

#### CONNECTING TO OSD MENU

1. Connect with AV cable
2. Press MENU and navigate through the menu with Remote

### STEP 3

#### MOUNTING

1. Place the camera in your designated spot, **charging battery can take up to 12 hours.**

## DIODE SIGNALS

#### DIODE


- GREEN** light
- 1X FLASH **RED**
- GREEN AND RED** 3x Flashing
- YELLOW** 3sec + **GREEN** 2sec
- 3x FLASH **GREEN**
- 3x FLASH **RED**
- 3x **YELLOW**
- GREEN** FLASHING

#### FUNCTION

- Stand-by
- Taking picture
- Not charged / shutting down
- Turning on
- Continuous recording
- Recording in PIR activation (best battery)
- Motion Detection (worse battery)
- SD Card is not inserted

## TIME SETTING

1. Create a .txt file called "time.txt"
2. Place in current date and time in following format:  
RRRR.MM.DD HH:MM:SS
3. Put on the SD Card in the core directory.



## USEFUL INFORMATION

If battery is fully discharged, charging will start 3 min after connecting the device into power supply.

**We recommend to format battery before you start using the device.**

Charge the device at least 6hours and then let it discharged. Repeat three times. After device will be fully formatted, charge it for 5 hours, ideally.

Record a sample video, to test the device under various light conditions.

## DISCLAIMER

This user manual can be slightly different from specific product.

Before start using the device, check with your local legal conditions. Neither supplier nor distributor assume responsibility for using device in conflict with local law.

## PACKAGE CONTAINS

- 1x Stronic UltraLife
- 1x Remote control
- 1x AV out Cable
- 1x Charging cable
- 1x USB Charger

